

OPERATOR'S MANUAL

Snap-on
SNAP-ON TOOLS CORPORATION

Snap-on®

18 V TORQUE TOOL







READ OPERATOR'S MANUALS



Product	Model	Image	Operator's Manual
Cordless Torque Multiplier (CTM series)	CTMXXXX		#34463 (EN)
CTB Battery Pack (CTB series)	CTB185		#ZCTB185CE Rev. A (EN)
CTC series 18 V Battery Charger (3-bay)	CTC123		#CTC123CE
CTC series 18 V Battery Charger (single bay)	CTC131		#ZCTC131CE

EN	English	Operator's Manual	Original Instructions	 #34463 + #34466 + #34468 
DA	Dansk / Danish	Betjeningsvejledning	Oversættelse af oprindelige instruktioner	
NL	Nederlands / Dutch	Handleiding	Vertaling Van De Originele Instructies	
FI	Suomi / Finnish	Käyttäjän opas	Käännös a lkuperäisistä ohjeista	
FR	Français / French	Manuel d'utilisation	Traduction des instructions originales	
DE	Deutsch / German	Bedienungsanleitung	Übersetzung der Originalanweisungen	
IT	Italiano / Italian	Manuale d'uso	Traduzione delle istruzioni originali	
PL	Polski / Polish	Instrukcja obsługi	Tłumaczenie oryginalnej instrukcji	
PT	Português / Portuguese	Manual do utilizador	Tradução das Instruções Originais	
ES	Español / Spanish	Manual del operario	Traducción de las instrucciones originales	
SV	Svenska / Swedish	Bruksanvisning	Översättning av bruksanvisning i original	

CONTENTS

Part Numbers Covered by This Manual	3
Serial Number	4
Safety Messages	5
Safety – General Power Tool Safety Warnings	5
Work Area Safety	5
Electrical Safety	6
Personal Safety	6
Power Tool Use and Care	6
Battery Tool Use and Care	7
Service	7
Safety – CTM Specific Safety Warning	8
Markings on Tool	8
CTM Tools without Reaction Bar	8
Introduction	9
Parts Included	9
Accessories	10
Features and Functions	12
Set Up Instructions	14
Battery	14
Torque Reaction	15
Display Features	18
Setting Menu	18
Operating Instructions	20
Tightening	20
Saving Results	22
Releasing	22
Maintenance	23
Daily Checks	23
Calibration	23
Gearbox	24
Drive Square	24
Battery Maintenance	24
Battery Charger Maintenance	24
Product Disposal	24
Specifications	25
Symbol Specifications	25
Tool Specifications	25
USB Bluetooth® Smart Adapter	29
EU Declaration of Conformity	30
UK Declaration of Conformity	31
Troubleshooting	32
Glossary of Terms	34

PART NUMBERS COVERED BY THIS MANUAL

This manual covers the set up and use of Snap-on® Battery Tools.

Model	Torque Range	Speed	Orientation	Case	Trigger	Part Number		
						Comms: BLE	Comms: LINK	Comms: NONE
CTM600	118 – 600 ft-lb	1	IL	KIT	Single	CTM600SSST	CTMLNK600SSST	CTM600SSNWST
					Dual	CTM600SS	CTMLNK600SS	CTM600SSNW
CTM1000	250 – 1000 ft-lb	1	IL	KIT	Single	CTM1000SSST	CTMLNK1000SSST	CTM1000SSNWST
				KIT	Dual	CTM1000SS	CTMLNK1000SS	CTMLNK1000SSNW
	250 – 1000 ft-lb	2	IL	KIT	Dual	CTM1000	CTMLNK1000	CTM1000NW
				KIT	Single	CTM1000ST	CTMLNK1000ST	CTM1000NWST
				BARE	Dual	CTM1000TB	-	-
				BARE	Single	CTM1000TBST	-	-
			RA	KIT	Dual	CTM1000RAGB	-	-
				KIT	Single	CTM1000STRAGB	-	-
				BARE	Dual	CTM1000TBAGB	-	-
				BARE	Single	CTM1000TBSTRAGB	-	-
CTM2000	500 – 2000 ft-lb	1	IL	KIT	Single	CTM2000SSST	CTMLNK2000SSST	CTM2000SSNWST
				KIT	Dual	CTM2000SS	CTMLNK2000SS	CTM2000SSNW
	500 – 2000 ft-lb	2	IL	KIT	Dual	CTM2000	CTMLNK2000	CTM2000NW
				KIT	Single	CTM2000ST	CTMLNK2000ST	CTM2000NWST
				BARE	Dual	CTM2000TB	-	-
				BARE	Single	CTM2000TBST	-	-
			RA	KIT	Dual	CTM2000RAGB	-	-
				KIT	Single	CTM2000STRAGB	-	-
				BARE	Dual	CTM2000TBAGB	-	-
				BARE	Single	CTM2000TBSTRAGB	-	-
CTM3000	738 – 3000 ft-lb	1	IL	KIT	Single	CTM3000SSST	CTMLNK3000SSST	CTM3000SSNWST
				KIT	Dual	CTM3000SS	CTMLNK3000SS	CTMLNK3000SSNW
	738 – 3000 ft-lb	2	IL	KIT	Dual	CTM3000	CTMLNK3000	CTM3000NW
				KIT	Single	CTM3000ST	CTMLNK3000ST	CTM3000NWST
				BARE	Dual	CTM3000TB	-	-
				BARE	Single	CTM3000TBST	-	-
			RA	KIT	Dual	CTM3000RAGB	-	-
				KIT	Single	CTM3000STRAGB	-	-
				BARE	Dual	CTM3000TBAGB	-	-
				BARE	Single	CTM3000TBSTRAGB	-	-

IMPORTANT: CTM TOOLS ARE SUPPLIED WITH BLUETOOTH MODULE (OPTION), LINK MODULE (OPTION) OR WITHOUT WIRELESS (OPTION). ALL TOOLS SUPPLIED WITH REACTION BAR. AUTO TWO SPEED TO ALLOW FAST RUNDOWN. KIT INCLUDES TOOL HANDLE + 3 BATTERIES + 1 CHARGER + PLASTIC CARRY CASE

Serial Number

The serial number is in the following format: **YYYYAXXXXX**

Serial Number	Description	Options		
YYYY*****	Year of manufacture			
****A*****	Month of manufacture	A=January D= April G=July K=October	B= February E= May H=August L=November	C= March F=June J=September M=December
*****XXXXX	Serial number			

NOTE: Due to the manufacturing process, the calibration date may be after the month of manufacture.


SAFETY MESSAGES

The safety messages are provided to cover reasonable situations that may be encountered when operating, servicing or repairing cordless tools. It is the responsibility of operators and servicing technicians to be knowledgeable about the procedures, tools and materials used, and to satisfy themselves that the procedures, tools and materials will not compromise their safety, that of others in the work place or the tool.

Use only with Snap-on® 18 V Battery Pack (CTB series) batteries.
Read Snap-on® Battery Pack (CTB series) Operator's Manual.

Charge only with Snap-on® Battery Charger (CTC131 or CTC123) equipment.
Read Snap-on® Battery Charger (CTC131 or CTC123) Operator's Manual.

SAFETY – GENERAL POWER TOOL SAFETY WARNINGS

Symbol	Meaning
	The exclamation mark is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the manual.



WARNING: READ ALL SAFETY WARNINGS, INSTRUCTIONS, ILLUSTRATIONS AND SPECIFICATIONS PROVIDED WITH THIS POWER TOOL. FAILURE TO FOLLOW ALL INSTRUCTIONS LISTED BELOW MAY RESULT IN ELECTRIC SHOCK, FIRE AND/OR SERIOUS INJURY.

Save all warnings and instructions for future reference. The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

Work Area Safety

- **Keep work area clean and well lit.** Cluttered or dark areas invite accidents.
- **Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- **Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

Electrical Safety

- **Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
- **Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
- **Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.
- **Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.

- **When operating a power tool outdoors, use an extension cord suitable for outdoor use.** *Use of a cord suitable for outdoor use reduces the risk of electric shock.*
- **If operating a power tool in a damp location is unavoidable, use a Ground Fault Circuit Interrupter (GFCI) protected supply.** *Use of a GFCI reduces the risk of electric shock*
- **AUSTRALIA/NEW ZEALAND: If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply.** *Use of an RCD reduces the risk of electric shock.*

Personal Safety

- **Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** *A moment of inattention while operating power tools may result in serious personal injury.*
- **Use personal protective equipment (PPE). Always wear eye protection.** *Protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection used for appropriate conditions will reduce personal injuries.*
- **Prevent unintentional starting. Ensure the switch is in the off-position before connecting to power source and/or battery pack, picking up or carrying the tool.** *Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.*
- **Remove any adjusting key or wrench before turning the power tool on.** *A wrench or a key left attached to a rotating part of the power tool may result in personal injury.*
- **Do not overreach. Keep proper footing and balance at all times.** *This enables better control of the power tool in unexpected situations.*
- **Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts.** *Loose clothes, jewellery or long hair can be caught*
- **If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** *Use of dust collection can reduce dust-related hazards.*
- **Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles.** *A careless action can cause severe injury within a fraction of a second.*

Power Tool Use and Care

- **Do not force the power tool. Use the correct power tool for your application.** *The correct power tool will do the job better and safer at the rate for which it was designed.*
- **Do not use the power tool if the switch does not turn it on and off.** *Any power tool that cannot be controlled with the switch is dangerous and must be repaired.*
- **Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools.** *Such preventive safety measures reduce the risk of starting the power tool accidentally.*
- **Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** *Power tools are dangerous in the hands of untrained users.*
- **Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use.** *Many accidents are caused by poorly maintained power tools.*
- **Keep cutting tools sharp and clean.** *Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.*

- **Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed.** *Use of the power tool for operations different from those intended could result in a hazardous situation.*
- **Keep handles and grasping surfaces dry, clean and free from oil and grease.** *Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.*

Battery Tool Use and Care

- **Ensure the switch is in the off position before inserting battery pack.** Inserting the battery pack into power tools that have the switch on invites accidents.
- **Recharge only with the charger specified by the manufacturer.** *A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.*
- **Use power tools only with specifically designated battery packs.** *Use of any other battery packs may create a risk of injury or fire.*
- **When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another.** *Shorting the battery terminals together may cause burns or a fire.*
- **Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help.** *Liquid ejected from the battery may cause irritation or burns.*
- **Do not use a battery pack or tool that is damaged or modified.** *Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.*
- **Do not expose a battery pack or tool to fire or excessive temperature.** *Exposure to fire or temperature above 248 °F (120 °C) may cause explosion.*
- **Follow all charging instructions and do not charge the battery pack or tool outside the temperature range specified in the instructions.** *Charging improperly or at temperatures outside the specified range may damage the battery and increase the risk of fire.*

Service



- **Have your power tool serviced by a qualified repair person using only identical replacement parts.** *This will ensure that the safety of the power tool is maintained.*
- **Never service damaged battery packs.** *Service of battery packs should only be performed by the manufacturer or authorized service providers.*

SAFETY – CTM SPECIFIC SAFETY WARNING

This tool is intended for use with threaded fasteners.

- It is recommended for the operator to wear hearing protection.
- Always use impact or high-quality sockets.
- Use only sockets and adaptors which are in good condition.
- Use only sockets and adaptors which are intended for use with power tools.
- Always operate with an approved reaction bar. Do not fix reaction bar to reaction point.
- Do not block cooling air entry and exit points.
- For very low torque rate joints (e.g. heat exchangers with long rundown threads) the tool will get warm. In extreme cases, the tool safety temperature control will stop the tool.
- Understand the operation of both the TORQUE target and the ANGLE target, especially when applied to pre-tightened fasteners. Incorrect tool use can easily apply excessive torque.
- Do not remove any labels. Replace all damaged labels.
- Do not lock or tape trigger, or 'safe to start' button, in the ON position.
- If the tool malfunctions, discontinue use and immediately arrange for service and repair.
- Do not lubricate or clean tools with flammable or volatile liquids such as kerosene, gasoline, diesel, or jet fuel.
- Store tool in carry case after use.

Markings on Tool

Pictograms on Tool	Meaning
	Read and understand Operator's Manual.
	Unexpected tool movement due to reaction forces or breakage of drive square or reaction bar may cause injuries. There is a risk of crushing between the reaction bar and work piece. Keep hands away from reaction bar. Keep hands away from tool output.

CTM Tools without a Reaction Bar





These tools MUST NOT be used until a suitable reaction bar has been fitted. The reaction bar is defined as 'interchangeable equipment' under the European directive 2006/42/EC on Machinery Safety.

INTRODUCTION








The Cordless Torque Multiplier (CTM) is an electronic torque tool designed for applying torque to threaded fasteners. There are models to cover torque capacities of 600 ft-lb to 3,000 ft-lb.



Parts Included

Kit	Case type:	Contents:
Kit	Plastic carry case	Tool handle 3 x Battery (Part CTB185) Charger (Part CTC123) (Additional items listed in below table)

Description	Model			
	CTM600	CTM1000	CTM2000	CTM3000
Maximum Torque	600 ft-lb	1,000 ft-lb	2,000 ft-lb	3,000 ft-lb
Visual Difference (1 speed / In-Line shown)				
Steel Cranked Reaction Bars	18646	MTMC19289	MTMC19289	MTMC19291
Reaction Bar Retaining Circlip	26588	MTMC26486	MTMC26486	MTMC26486
Drive Square (fitted)	18544	18492 (1")	19431 (1")	MTMC18934 (1")
Drive Square (spare)	18544	18779 (3/4")	19431 (1")	MTMC18934 (1")
4 mm Hex Key for Drive Square	24953	24953	24953	24953
CTM Operator's Manual	34463	34463	34463	34463
USB memory stick with EvoLog PC software & Operator's Manual	61139	61139	61139	61139
USB lead (2 m)	39777	39777	39777	39777
USB Bluetooth® Smart adapter (option)	54513	43513	43513	43513
Secondary Handle	-	19363	19448	19363

Accessories

Description	Model			
	CTM600	CTM1000	CTM2000	CTM3000
$\frac{3}{4}$ " Drive Square (Fixing Screw)	18544 (25351.30)	18779 (25325.45)	-	-
1" Drive Square (Fixing Screw)	18545 (25351.30)	18492 (25352.45)	19431 (25352.40)	18934 (25352.60)
1 $\frac{1}{2}$ " Drive Square (Fixing Screw)	-	-	-	18935 (25352.60)
 Reaction Bar (NOTE)	SRP18298	SRP18298	-	-
 Reaction Bar Adaptor (NOTE)	RA18558	RA18290	-	-
 Single-Sided Reaction Plate	MTMC18576	MTMC18292	MTMC18292	MTMC18979
 Double-Sided Reaction Plate	MTMC18590	MTMC18293	MTMC18293	MTMC18980
 Sliding Reaction Plate	-	$\frac{3}{4}$ " SR72B06 (1") SR72B08	180300.080.B08	(1") SR92B08
 Aluminium Cranked Reaction Foot	-	ACR18494	ACR18494	ACR18936
6" Blade Nose Extension	$\frac{3}{4}$ " 18601.006	ME72B06L	-	-
9" Blade Nose Extension	$\frac{3}{4}$ " 18601.009	ME72B09L	-	-
12" Blade Nose Extension	$\frac{3}{4}$ " 18601.012	ME72B12L	-	-
9" Nose Extension for Truck and Bus Wheels	-	WTE4G72L9	-	-
 Battery	CTB185	CTB185	CTB185	CTB185

Secondary Handle		-	19363	19448	19363
Charger		CTC123	CTC123	CTC123	CTC123

NOTE: Requires both "Reaction Bar" and "Reaction Bar Adaptor" to be used together.

Reactions to suit specific applications can be supplied, contact distributor for details.

FEATURES AND FUNCTIONS



FIGURE 1 – Tool Features

- Brushless motor for low maintenance
- Trigger and 'safe to start' button, if fitted, to ensure hands are safely positioned
- High powered LED light to illuminate application
- 18V, 5.0Ah battery and efficient motor give outstanding fastening performance per charge
- OLED display ensures visibility in all conditions
- Key Lock feature prevents unauthorised usage
- Tool is uninhibited by power cable or hose, improving safety, convenience and versatility
- Multiple units of torque measurement, including N·m, lbf·ft, ft·lb and kgf·m
- Torque, Torque & Angle with Final Torque and Torque Audit mode targets available
- Display and on-board storage of Final Torque or Torque & Angle values
- 2500 reading memory, time and date stamped

- **Two modes of operation:**
 1. 'Torque only' is the default mode for the first-time user; only torque targets can be set and data storage / transfer is limited
 2. 'Advanced' allows angle targets and full data storage / transfer
- Sleep feature to turn off display to save battery power; default time 20 seconds
- Clear indication of successful joint application
- Data transfer options include wired USB (all models), wireless Link (optional) or Bluetooth® 4.0 (optional) for connection to PC dongle
- Complimentary EvoLog PC software for data management and tool configuration
- 12 user IDs can be downloaded to the tool and results can be stored against individual users
- 20 stand-alone targets, plus 5 work groups each containing up to 20 targets
- Ability to produce and store real time graphs via EvoLog PC Software
- 'Usage' counter gives the ability to see the amount of times the tool has been used since the last reset
- 'Operation Direction' feature designed primarily for undoing bolts. When doing sequence tightening, it is now possible to undo an incorrectly tightened bolt without interrupting the sequence
- 'Turn Angle' measures bolt rotation to detect if bolt was already tight
- 'User' output format for tool integration into third party control systems
- Tool models with 2 speeds (for faster bolt rundown) and right-angle drive (for bolt access)



FIGURE 2 – User Interface Features

SET UP INSTRUCTIONS

NOTE: If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.



WARNING: ALLOW THE TOOL TO EQUALISE TO THE AMBIENT TEMPERATURE / HUMIDITY BEFORE SWITCHING ON. WIPE OFF ANY MOISTURE BEFORE USE.

Please complete the set up in the order shown.

Battery

Use Snap-on® CTB185 or CTB8187 Battery Packs with this tool.

1. Insert battery into tool handle until latch operates.
2. To remove battery press both side latch buttons and slide battery out.



FIGURE 3 – Insert & remove battery

It is recommended to remove the battery pack during tool set up.

Charge battery in separate Snap-on® Battery Charger (CTC123 Series Battery Charger)



FIGURE 4 – Insert battery into charger

Torque Reaction

The reaction bar ensures all reaction forces are contained, so torque reaction is not passed back to the operator. Several reaction bar styles are available.

Fit reaction bar as detailed below.

Reaction Bar Type	Fitting Instructions
Cranked Reaction Bar (Standard)	Fit reaction bar / plate over the drive square to engage reaction splines. Secure with circlip supplied.
Single Sided Reaction Plate (Optional)	
Double Sided Reaction Plate (Optional)	
Nose Extension (Optional)	Fit as per instructions supplied with nose extension.



FIGURE 5 – Nose Extension

It is essential the reaction bar rests squarely against a solid object or surface adjacent to the fastener to be tightened.

DO NOT react on the surface circled in red on figure 6.

React on the end of the reaction bar, circled in green on figure 6, using the maximum area possible.




FIGURE 6 – Cranked Reaction Bar (Steel or Aluminium)

The ideal reaction arrangement has the centre of the reaction bar and the centre of the nut on a perpendicular line to the centre line of the tool, see Figure 7.

The supplied reaction bar has been designed to give an ideal reaction point when used with a standard length socket.

To allow for a small difference in socket length the reaction bar may contact any point within the shaded area of Figure 7.




FIGURE 7 – Standard Length Socket Safe Reaction Window



WARNING: IF THE REACTION POINT IS OUTSIDE THE SHADED AREA EXCESSIVE LOADS MAY BE PLACED ON THE TOOL LEADING TO POTENTIAL OPERATOR INJURY AND DAMAGE TO THE TOOL.

If an extra long socket is used it may move the reaction bar outside the safe reaction window, as seen in Figure 8.

The standard reaction bar may need to be extended to ensure it remains within the shaded area.

For alternative reaction bars see ACCESSORIES list.



WARNING: IF MODIFYING THE STANDARD REACTION BAR, ENSURE IT IS CAPABLE OF TAKING THE MAXIMUM LOAD OF THE TOOL. FAILURE OF THE REACTION BAR CAN ENDANGER OPERATOR SAFETY AND DAMAGE THE TOOL.




FIGURE 8 – Extra Long Socket Safe Reaction Window

Long drive square extensions, see Figure 9, MUST NOT be used as these will cause serious damage to the tool output drive.

A range of nose extensions is available for applications where access is restricted. These are designed to support the final drive correctly.

The dimensions of the standard reaction bars are shown in the following table:



FIGURE 9 – Drive Square Extension





Steel Reaction Bar (Supplied)	Tool	'L' (mm)	'A' (mm)	'B' (mm)	'W' (mm)	'SQ' (INCH)
	CTM600	59	131	71	35	3/4"
	CTM1000	77	167	124	29	3/4" or 1"
	CTM2000	75	175	125	29	1"
	CTM3000	95	210	161	35	1 1/2"

FIGURE 10 – Reaction Bar

Nose Extension for Truck and Bus Wheels (Optional Accessory)	'L' (mm)	'A' (mm)	'B' (mm)	'C' (mm)	ØD	ØE	'SQ' (INCH)
	98	47	132.5	29	52	38	3/4" or 1"

FIGURE 11 – Nose Extension for Truck and Bus Wheels

When the CTM is in operation the reaction bar rotates in the opposite direction to the output drive square and must be allowed to rest squarely against a solid object or surface adjacent to the fastener to be tightened. (See Figures 12 – 15).





CTM Type	Torque Reaction	
	Clockwise	Counter-Clockwise
Example of CTM Tool	 <p>FIGURE 12</p>	 <p>FIGURE 13</p>
	 <p>FIGURE 14</p>	 <p>FIGURE 15</p>



WARNING: ALWAYS KEEP HANDS CLEAR OF THE REACTION BAR WHEN THE TOOL IS IN USE OR SERIOUS INJURY MAY RESULT.





Display Features




Button	Action
	Exit / Setting menu
	Select menu & increase / decrease value TIP: Keep button pressed for fast value change
	Accept / Direction
	Save / no save

If locked padlock appears, enter PIN code.
Any default value is shown as the first option.







Setting Menu

Settings Menu	Detail	Action
	If the setting menu has 3 icons the MODE is set to "Torque only". This is the default setting menu.	Follow "(i) MODE Torque only"
	If the setting menu has 6 icons the MODE is set to "Advanced".	Follow "(ii) MODE Advanced"

(i) MODE Torque only:

Setting	Icon	MODE Torque only
Targets		Select Target # (T01 – T20). Set target torque.
Settings		Unit (N·m, lbf·ft, ft·lb or kgf·m) Auto Reset (✘ = Manual Reset / ✔ = Auto Reset). Time & Date (hh:mm:ss dd – mm – yy) Operation Direction ("⤵+⤴"= clockwise target + counter-clockwise target, "⤴" or "⤵" sets full torque in opposite direction for undoing fasteners) Mode (Torque only / Advanced) Sleep Time 20 sec (Off to 10 - 3600 sec)
Information		Tool capacity, Time & date. Tool serial #, Tool name. Software version [D=Display, M=Motor & B=Bluetooth]. Error Log. Tool Statistics. Tool usage.

(ii) **MODE Advanced:**

Setting	Icon	MODE Advanced
Targets		<p>Select Target # (T01 – T20). Set target torque. Set target angle (0 = no angle). Set final torque (0 = not enabled). Audit mode '✘' or '✔'? Set angle limit (for Audit mode) = 5° (2° to 720°).</p>
Work Groups & Work IDs		<p>Tracks the work done. See EvoLog PC software to add work groups.</p>
User ID.		<p>Tracks who is using the tool. See EvoLog PC software to add users.</p>
Settings		<p>Unit (N·m, lbf·ft, ft·lb or kgf·m) Auto Reset (✘ = Manual Reset / ✔ = Auto Reset). Lock (Off = Unlocked. 1 = Tool settings, Erase results & Target adjustment locked. 2 = Run screen with no multiple Targets locked). The PIN code set 0000 to 9999 [default 5000] TIP: Keep a note of the pin code in a safe place TIP: Lock 2 needs PC software to unlock. Wireless Comms? (✘ = OFF / ✔ = ON) Disabled on CTMXXXXNW models Time & Date (hh:mm:ss dd – mm – yy) Tolerances (Torque 3% [range 3 – 20], Angle 2° [range 2 – 20], Turn > 0° [range 0 – 99]. Output Format (USER = CSV output for custom use / EVOLOG for CTM PC software) 2 Stage Target (✘ = Snug with angle / ✔ = Snug stage + Angle stage) Operation Direction (“⤵+⤴” = clockwise target + counter-clockwise target, “⤴” or “⤵” sets full torque in opposite direction for undoing fasteners) Mode (Torque only / Advanced) Sleep Time 20 sec (Off to 10 - 3600 sec)</p>
View Results		<p>View results & Erase all. For more data control use EvoLog PC software.</p>
Information		<p>Tool capacity, Time & date. Tool serial #, Tool name. Software version [D=Display, M=Motor & B=Bluetooth]. Error Log. Tool Statistics. Tool usage.</p>

OPERATING INSTRUCTIONS



WARNING: KEEP HANDS CLEAR OF THE REACTION BAR.



WARNING: WHEN USING THIS TOOL IT MUST BE SUPPORTED AT ALL TIMES IN ORDER TO PREVENT UNEXPECTED RELEASE IN THE EVENT OF FASTENER OR COMPONENT FAILURE.


Tightening

1. Fit the tool with required impact or high-quality socket. Slide the socket over the tool square drive ensuring the pin hole in both socket and square drive line up. Insert holding pin through the hole and place the retaining ring over the holding pin to secure.



FIGURE 16 – Fixing socket


2. Ensure the Clockwise/Counter-clockwise display arrow is correct.

Press  to change direction (if required).

3. Ensure Torque, Torque & Angle or Audit Torque target shown is correct.

Torque

Torque is applied until the target torque is reached.




Torque & Angle

The tool applies the target torque (snug torque) followed by the target angle.

With 'Final Torque' enabled, a torque result at the target angle is known.

With '2 Stage Target' enabled, the 1st stage applies the Torque then 2nd stage applies the Angle. Release the trigger between stages.




Audit Torque

Audit Torque is intended for checking tight bolts.

The tool runs slower.

Torque is applied until the target torque is reached.

The angle result is the angle moved by the fastener.



- Rotate the handle into a convenient position relative to the reaction bar.
Fit the tool onto the fastener to be tightened with the reaction bar adjacent to the reaction point. See figure 17.
- Adopt a posture to counteract normal or unexpected movement of the tool due to reaction forces.
- Press trigger (and 'safe to start' button if fitted within 0.5 seconds) to slowly bring reaction bar into contact with the reaction point. The 'safe to start' button is only required to start the tool, not for continued running.

NOTE: Bringing into contact at speed can lead to increased operator danger, fastener damage, reaction point damage and torque inaccuracies especially on high torque rate joints.



FIGURE 17–Clockwise Operation

- Fully press trigger (and 'safe to start' button if fitted), keep trigger fully pressed until tool stops, then release trigger.
- Joint complete. See colour of displayed value for pass / fail status

Target	Torque	Torque & Angle	Audit Torque
Typical display			
Comment	Torque Target result (shown as red for fail)	Torque & Angle target (with Final Torque) result (shown as green for pass)	Audit Torque target result (showing achieved torque and output (bolt) movement in degrees)

- Remove the tool from the fastener.

TIP: When tightening multiple fasteners on a flange it is recommended to mark each fastener when tight.



The Turn Angle setting can be used as a means of identifying an already tightened fastener.


This is even more important when using the TORQUE & ANGLE target as applying additional angle to a tightened fastener will increase the risk of operator danger, fastener damage and flange damage.


Saving Results

Auto Reset = Button Operation (after a successful tightening)


X

Press either the  or  buttons to Save the displayed (joint complete) reading and reset the tool, ready for the next tightening operation.

Press the  button to reset the tool ready for the next tightening operation **without** saving the (joint complete) reading.

Press the  button to toggle between Save and No Save.

✓

When the Save icon  is displayed, the next displayed (joint complete) reading will be saved and automatically reset the tool ready for the next tightening operation after the 'Hold Time' setting has expired.

The next displayed (joint complete) reading will **not** be saved if the icon is not shown.

NOTE: The Save icon will be shown in red when the tool is in 'Logging' mode. See EvoLog PC software Operator's Manual (part number 34427) for more details.

Releasing

1. Fit the tool with required impact or high-quality socket. Slide the socket over the tool square drive ensuring the pin hole in both socket and square drive line up. Insert holding pin through the hole and place the retaining ring over the holding pin to secure.



FIGURE 18 – Fixing socket

2. Ensure the clockwise/counter-clockwise display arrow is correct.

Press  to set direction.

3. Rotate the handle into a convenient position relative to the reaction bar. Fit the tool onto the fastener to be released with the reaction bar adjacent to the reaction point. See figure 19.

4. Adopt a posture to counteract normal or unexpected movement of the tool due to reaction forces.
5. Press trigger (and 'safe to start' button, if fitted) to slowly bring reaction bar into contact with the reaction point. The 'safe to start' button is only required to start the tool, not for continued running.
6. Fully press trigger (and 'safe to start' button, if fitted) and keep trigger fully pressed until the threaded fastener releases.

TIP: If unable to release the fastener, increase the target torque. The tool will automatically limit itself to the maximum output torque.



FIGURE 19 – Counter-Clockwise Operation

MAINTENANCE

For optimum performance and safety, regular tool maintenance is required. The user maintenance is limited to that stipulated in this section. Any other maintenance or repairs should be carried out by a Snap-on® distributor. After any repair not covered in this section a recalibration must be completed.' 'For contact addresses see page number 23 of this manual'.



WARNING: THE TOOL FEATURES A LITHIUM BATTERY. ALL LITHIUM BATTERIES ARE SUBJECT TO TRANSPORT LIMITATIONS WITH STRICT PACKAGING AND LABELLING CONDITIONS. TOOLS MAY BE EASIER TO RETURN WITHOUT THE LITHIUM BATTERY. ASK A SNAP-ON DISTRIBUTOR BEFORE RETURNING TOOL.

Maintenance intervals will depend on the tool usage and the environment in which it is being used. The maximum recommended maintenance and recalibration interval is 12 months.

TIP: Steps the user can take to reduce the amount of maintenance required include:

- 1. Use the tool in a clean environment**
- 2. Maintain the correct torque reaction**
- 3. Carry out daily checks**

The tool has no user serviceable parts inside.



WARNING: REMOVE THE BATTERY PACK FROM THE TOOL BEFORE INVESTIGATING ANY FAULT. SHORT-CIRCUITING THE BATTERY PACK CAN CAUSE FIRE OR PERSONAL INJURY.

Daily Checks

- It is recommended to check the overall condition of the tool, battery & charger every day.
- Check for damaged parts and repair before use.
- Free run tool to ensure motor and gearbox are smooth and quiet.
- Run tool to ensure controls are operational.
- Check charger power cord for damage – replace if faulty.
- Ensure charger PAT test is within date.
- Maintain tools. Keep tools dry, clean and free of oil and grease - DO NOT use abrasives or solvent based cleaners.
- Ensure ventilation slots are clean and dust free. If cleaned with compressed air wear eye protection.

Calibration

The tool was supplied with a certificate of calibration. To maintain the specified accuracy, it is recommended that the tool is recalibrated at least once per year.

Recalibration should be carried out by a distributor with the facilities and traceability to perform a calibration. Do not remove tool casing; there are no calibration settings inside.

Gearbox

Under normal operating conditions it is not necessary to re-grease the gearbox. The gearbox contains Lubcon Turmogrease Li 802 EP.

Drive Square

If the tool is subject to torque overload there is potential for catastrophic tool damage. To reduce this risk the output drive square has been designed, like a fuse, so it will shear first. The output drive square is easy and quick to replace, for part numbers see ACCESSORIES listed in the INTRODUCTION. The drive square is NOT covered by the standard product warranty.

To replace the drive square:

1. Remove battery.
2. Support tool in a horizontal position
3. Use 4 mm hex key (supplied) to remove the screw and then remove

drive square. If the square has sheared it may be necessary to use pliers to remove the broken parts.



FIGURE 20 – Drive square removal

Battery Maintenance

Refer to CTM Operator's Manual (Part #ZCTB185CE Rev. A).

If the battery does not hold charge it should be replaced. The old battery should be disposed of correctly.

Battery Charger Maintenance

Refer to CTC123 Operator's Manual (Part #ZCTC123CE Rev. B).

Product Disposal



This symbol on the product indicates that it must not be disposed of in the general waste.

Please dispose of according to your local recycling laws and regulations. Contact your distributor for further recycling information.

Contact Us (United Kingdom)

Snap-on® Tools UK Customer Service

For information or help regarding any Snap-on® Tools products, or if you need to contact your local Snap-on Tools franchisee:

Tel: +44 (0)1536 413990

Monday - Friday 8.00am - 5.30pm

Email: techsales.uk@snapon.com

Contact Us (United States)

Snap-on® Industrial Customer Service Center

Tel: +1 877 740 1900

Fax: +1 888 418 5900






Monday – Friday 7.00 am CT – 6.00pm CT

For more information, contact your Snap-on Industrial account manager
Email: order@snapon.com

SPECIFICATIONS

NOTE: Due to continuous improvement, all specifications are subject to change without prior notice.

Symbol Specifications

Symbol	Meaning
	REFER TO OPERATORS MANUAL
V	VOLT
	US AND CANADIAN UL LISTED
	CE MARK
	UK CONFORMITY ASSESSED
	DO NOT THROW IN GENERAL WASTE
— — —	DIRECT CURRENT

Tool Specifications

Model	Torque	Tool Speed Free Running*
	Calibrated Range	
CTM600 Single Speed	118 – 600 ft-lb	11.3 rpm
CTM1000 Single Speed	148 – 1,000 ft-lb	6.5 rpm
CTM1000 2-Speed	250 – 1,000 ft-lb	32 rpm
CTM2000 Single Speed	295 – 2,000 ft-lb	3.3 rpm
CTM2000 2-Speed	500 – 2,000 ft-lb	13 rpm
CTM3000 Single Speed	590 – 3,000 ft-lb	2.3 rpm
CTM3000 2-Speed	738 – 3,000 ft-lb	9.5 rpm

* = Tool speed is reduced for Audit mode

Model	Tool Weight (kg)*	Battery Weight (kg)	Reaction Weight (kg)	Bare tool in cardboard box (kg)**	Kit tool in plastic case (kg)***
CTM600	3.7	0.8	0.85	6.1	14.9
CTM1000	5.9	0.8	1.7	9.1	17.9
CTM2000	6.8	0.8	1.7	10.0	18.8
CTM3000	8.3	0.8	2.5	12.3	21.1

* = Tool weight excludes both reaction and battery.

** = Tool weight is for In-Line gearbox (for Right Angle gearbox add 2.1 kg). Reaction included. Battery & Secondary Handle NOT included.

*** = Tool + 3 Batteries + Battery Charger. Tool weight is for In-Line gearbox (for Right Angle gearbox add 2.1 kg) Reaction included. Secondary handle NOT included.

Model	Dimensions (mm)											
	ØD	H1	H2	H3*	H4*	L*	L1	L2	R1	R2 min	R2 max	W
CTM600	52	40	262	171	28	271	269	235	59	68	131	90
CTM1000	72	40	262	198 (217)	28	298 (317)	269	235	76	124	167	90
CTM2000	80	40	262	191 (226)	28	298 (333)	269	235	76	124	167	90
CTM3000	92	40	262	250 (285)	28	352 (387)	269	235	70	125	175	92

* = Length for 1 speed (length for 2 speed).




FIGURE 21 – Tool Dimensions

Angle Setting:	10° to 720°
Angle Start Threshold:	10% to 100% of tool capacity
Display:	Colour OLED (160 x 128 pixels)
Motor Voltage:	18.0 VDC
Memorised readings:	2500
Vibration emission:	The vibration total value does not exceed 2.5m/s ² Measured tool vibration (ah) = 0.9 m/s ² with uncertainty K = 0.22 m/s ² Noise emission: Sound Pressure Level, L _{pA} = 79.1 dB(A) uncertainty K = 3dB

The declared vibration and noise emission values have been measured in accordance with a standard test method and may be used for comparing one tool with another.

The declared vibration and noise emission values may also be used in a preliminary assessment of exposure.



WARNING: THE VIBRATION AND NOISE EMISSIONS DURING ACTUAL USE OF THE POWER TOOL CAN DIFFER FROM THE DECLARED VALUES DEPENDING ON THE WAYS IN WHICH THE TOOL IS USED ESPECIALLY WHAT KIND OF WORKPIECE IS PROCESSED.



WARNING: IDENTIFY SAFETY MEASURES TO PROTECT THE OPERATOR THAT ARE BASED ON AN ESTIMATION IN THE ACTUAL CONDITIONS OF USE (TAKING ACCOUNT OF ALL PARTS OF THE OPERATING CYCLE SUCH AS THE TIMES WHEN THE TOOL IS SWITCHED OFF AND WHEN IT IS RUNNING IDLE IN ADDITION TO THE TRIGGER TIME).

Environment:	Industrial. Store in a clean and dry environment
Temperature Range:	-4°F to +120°F (operating). -4°F to +120°F (storage)
Operating Humidity:	85% Relative Humidity @ 86°F maximum
USB:	2.0
Bluetooth®: (Option)	Bluetooth® Smart 4.0 for use will USB smart adaptor supplied "Contains Transmitter Module FCC ID: QOQBLE112" "Contains Transmitter Module IC: 5123A-BGTBLE112" Frequency: 2.402 GHz to 2.480 GHz Maximum power transmitted: +3dBm to -23dBm Wireless range tested to 6m. Can work over 20m in an ideal environment
Link (XBee): (Option)	"Contains Transmitter Module FCC ID: MCQ-XBS2C" "Contains Transmitter Module IC: 1846A-XBS2C" Frequency: 2.405 GHz to 2.480 GHz Maximum power transmitted: 12.65mW (11.02 dBm) EIRP Wireless range tested to 6m. Can work over 20m in an ideal environment

FCC and IC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

FCC Caution: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Industry Canada

IC Statements:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be chosen so that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Déclaration d'IC :

Ce dispositif est conforme aux normes RSS exemptes de licence d'Industrie Canada. Son fonctionnement est assujéti aux deux conditions suivantes : (1) ce dispositif ne doit pas provoquer de perturbation et (2) ce dispositif doit accepter toute perturbation, y compris les perturbations qui peuvent entraîner un fonctionnement non désiré du dispositif.

Selon les réglementations d'Industrie Canada, cet émetteur radio ne doit fonctionner qu'avec une antenne d'une typologie spécifique et d'un gain maximum (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Pour réduire les éventuelles perturbations radioélectriques nuisibles à d'autres utilisateurs, le type d'antenne et son gain doivent être choisis de manière à ce que la puissance isotrope rayonnée équivalente (P.I.R.E.) n'excède pas les valeurs nécessaires pour obtenir une communication convenable

USB BLUETOOTH® SMART ADAPTOR SPECIFICATION (WHERE INCLUDED)



CE

USB Bluetooth® Smart adapter is in conformity with the essential requirements and other relevant requirements of the RED Directive (2014/54/EU).

South-Korea

USB Bluetooth® Smart adapter is certified in South-Korea with certification number: KCC-CRM-BGT-BLED112

Japan

USB Bluetooth® Smart adapter has MIC Japan type certification with certification number: 003WWA111471

Brazil



Este equipamento opera em caráter secundário, isto é, não tem direito à proteção contra interferência prejudicial, mesmo de estações do mesmo tipo e não pode causar interferência a sistemas operando em caráter primário.

EU DECLARATION OF CONFORMITY

This declaration of conformity is issued under the sole responsibility of the manufacturer:

The object of the declaration: Torqueing Tool

Model name Cordless Torque Multiplier (CTM)

CTM600****, CTMLNK600****
 CTM1000****, CTMLNK1000****
 CTM2000****, CTMLNK2000****
 CTM3000****, CTMLNK3000****
 (* = optional feature)

Model No 180733.SNP → 181208.SNP
 Serial Number 2019KXXXXX → XXXXXXXXXXXX

The object of the declaration: Battery Charger

Model No CTC123 & CTC131
 Serial Number 1539XXXX → XXXXXXXX & 1718XXXX → XXXXXXXX

The object of the declaration: Battery Pack

Model No CTB185 & CTB187
 Serial Number 1826XXXX → XXXXXXXX & 2027XXXX → XXXXXXXX

The object of the declaration described above is in conformity with the relevant union harmonisation legislation:

DIRECTIVE	PRODUCT
Directive 2006/42/EC on Machinery.	CTM
Directive 2014/30/EU on Electromagnetic Compatibility.	CTM, CTC & CTB
Directive 2014/53/EU on Radio Equipment.	CTM
Directive 2011/65/EU of the European Parliament and of the Council of 8 June 2011 on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS).	CTM, CTC & CTB
Directive 2014/35/EU on Low Voltage Equipment	CTC

References to the relevant harmonised standards used or references to the specifications in relation to which conformity is declared:

STANDARD(S)	PRODUCT
EN 62841-1:2015/AC:2015 & EN 62841-2-2:2014/AC:2015 EN 55014-1:2006+A1:2009+A2:2011 & EN 55014-2:2015 EN 301 489-1 v.2.1.1, EN 301 489-17 v3.1.1 & EN 300 328 v2.1.1	CTM
EN 60335-1:2012+A11:2014 & EN 60335-2-29:2004+A2:2010 EN 55014-1:2006+A1:2009+A2:2011 & EN 55014-2:1997+A1:2001+A2:2008	CTC
EN 55014-1:2006+A1:2009+A2:2011 & EN 55014-2:1997+A1:2001+A2:2008	CTB

The CE mark was first applied in: 2019 (CTM), 2015 (CTCEU123), 2017 (CTCEU131), 2018 (CTB185) & 2020 (CTB8187).

The authorized representative within the European Union (EU) is:

Francesco Frezza Snap On Equipment Via Prov. Carpi, 33 42015 Correggio RE Italy

Signed for and on behalf of Snap On.

Signed: 

Full Name: Charles R Frontczak.

Date: 17th November 2021

Authority: Director of Cordless Engineering

Place: Snap-on Tools Company, 2801 80th Street, Kenosha, WI 53141-1410, U.S.A.

UK DECLARATION OF CONFORMITY

This declaration of conformity is issued under the sole responsibility of the manufacturer:

The object of the declaration: Torqueing Tool

Model name Cordless Torque Multiplier (CTM)

CTM600****, CTMLNK600****
 CTM1000****, CTMLNK1000****
 CTM2000****, CTMLNK2000****
 CTM3000****, CTMLNK3000****
 (* = optional feature)

Model No 180733.SNP → 181208.SNP
 Serial Number 2019KXXXXX → XXXXXXXXXXXX

The object of the declaration: Battery Charger

Model No CTC123 & CTC131
 Serial Number 1539XXXX → XXXXXXXX & 1718XXXX → XXXXXXXX

The object of the declaration: Battery Pack

Model No CTB185 & CTB187
 Serial Number 1826XXXX → XXXXXXXX & 2027XXXX → XXXXXXXX

The object of the declaration described above is in conformity with the relevant UK statutory requirements:

DIRECTIVE	PRODUCT
Supply of Machinery (Safety) Regulations 2008	CTM
Electromagnetic Compatibility Regulations 2016	CTM, CTC & CTB
Radio Equipment Regulations 2017	CTM
The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012	CTM, CTC & CTB
Electrical Equipment (Safety) Regulations 2016	CTC

References to the relevant harmonised standards used or references to the specifications in relation to which conformity is declared:

STANDARD(S)	PRODUCT
BS EN 62841-1:2015 & BS EN 62841-2-2:2014	CTM
BS EN 55014-1:2006+A2:2011 & BS EN 55014-2:2015 ETSI EN 301 489-1 v.2.1.1, ETSI EN 301 489-17 v3.1.1 & ETSI EN 300 328 v2.1.1	
BS EN 60335-1:2012+A11:2014 & BS EN 60335-2-29:2004+A2:2010	CTC
BS EN 55014-1:2006+A2:2011 & BS EN 55014-2:1997+A2:2008	
BS EN 55014-1:2006+A2:2011 & BS EN 55014-2:1997+A2:2008	CTB

The UKCA mark was first applied in: 2021 (CTM), 2021 (CTCEU123), 2021 (CTCEU131), 2021 (CTB185) & 2021 (CTB8187).

The authorized representative located within the United Kingdom (UK) is:

Matthew Law Snap-on Tools Ltd Telford Way Industrial Estate, Kettering, Northants. NN16 8SN United Kingdom


Signed for and on behalf of Snap On.

Signed:  Full Name: Charles R Frontczak.

Date: 17th November 2021 Authority: Director of Cordless Engineering
 Place: Snap-on Tools Company, 2801 80th Street, Kenosha, WI 53141-1410, U.S.A.

TROUBLESHOOTING

The following is only a guide, for more complex fault diagnoses please contact your distributor.

Problem	Likely Reason	Likely Solutions
No Display	Sleep time active Flat battery	Pull trigger to wake up tool Change / charge battery
Display reads 'Warning Below Calibrated Value'	Tool set below calibrated range	If calibrated range required increase torque
Tool output drive does not rotate when trigger is pressed	'safe to start' button NOT pressed	Press trigger + 'safe to start' button at the same time (within approximately half a second) to run tool
	Tool is on tight fastener	Remove from fastener Check correct setting of tool direction
	Tool is off	Ensure tool is ON (display lit)
	Tool is in set up screen	Exit set up to return to operate screen
	Output drive square sheared	See MAINTENANCE section to replace drive square
	Gear train or motor is damaged	Contact Snap-on®.
Result shown in Red	Bolt has not made correct torque or angle	Trigger released early  Fastener sheared or thread stripped
Measured angle is less than tool applied	Flex in reaction bar or reaction point	Ensure reaction bar & reaction point are rigid
E>1350, E>2700, E>4000	Demand for torque greater than tool capacity	Use larger capacity tool
Tool runs slower at lower Targets or in Audit mode	Normal operation	Normal operation
	Slam joint. a) The reaction bar is moving too fast (tightening) b) Un-doing a tightened joint with too low a Target	Undo and re-tighten the joint Use a larger Target value than the tightening Target
Not working with PC software	Output Format has been set to USER	Change the Output Format to PC software
Lost PIN number	Contact Snap-on®	
Battery symbol shown in power up	Low time/date battery. Contact Snap-on®	
	a) Turn Angle set too High b) Joint already tight	Decrease Turn Angle setting
Tool stops, with 4 flashing LED's on battery	Battery over temperature, 158°F (70°C) detected	Wait for battery to cool Place battery on charger to take advantage of charger cooling fan
Tool stops, with left battery LED flashing	Battery voltage low	Charge battery
Tool Error Release Trigger	A fault has occurred, please release both of the triggers.	Release both triggers.

Problem	Likely Reason	Likely Solutions
FWD/REV Signal Error	M.C.U. has not received a direction signal.	Release both triggers. If problem persists, contact Snap-on®.
Motor Over Temperature	Motor too hot.	Wait for the motor to cool.
M.C.U. Over Temperature	Motor Control Unit too hot.	Wait for the motor control unit to cool.
MOSFET Over Temperature	MOSFET in motor power circuitry too hot.	Wait for the MOSFET circuitry to cool.
Over Voltage Error	Battery voltage exceeds 22V.	Remove the current battery, before connecting a fully-charged battery to the tool. If problem persists, contact Norbar.
Under Voltage Error	Battery voltage has fallen below 13V during bolting operation.	Remove the current battery, before connecting a fully-charged battery to the tool. If problem persists, contact Snap-on®.
Short Circuit Protection	An electrical short has been detected between the battery and the M.C.U..	Release both triggers. If problem persists, contact Snap-on®.
Phase Open Protection	Motor Control Unit is unbalanced; it is not safe for the motor to start.	Disconnect, then re-connect the battery to the tool. If problem persists, contact Snap-on®.
Motor N.T.C. Open	Thermistor on motor is currently open circuit.	Disconnect, then re-connect the battery to the tool. If problem persists, contact Snap-on®.
MOSFET N.T.C. Open	Thermistor on MOSFET is currently open circuit.	Disconnect, then re-connect the battery to the tool. If problem persists, contact Snap-on®.
Hall Sensor Error	A connection or synchronization issue has occurred with the motor sensors.	Contact Snap-on.
Low Voltage Start	Battery voltage is below 13V on trigger press.	Remove the current battery, before connecting a fully-charged battery to the tool.
Rotor Lock	Motor speed < 300 R.P.M. for 200ms or longer.	Release both triggers. If problem persists, contact Snap-on®.
Hard Current Limit	Motor current has exceeded safe level for 1-2 seconds.	Release both triggers. If problem persists, contact Snap-on®.
Torque Shutoff Before Angle	Tool is perceived to be operating beyond its safe capacity.	Operate tool within stated capacity only.
Tool Cannot Zero	Tool auto-zero process is unable to “zero” the transducer within the A.D.C. range.	Ensure that the transducer is electrically connected, and mechanically secured. Verify that the transducer has not been damaged/heavily deflected through usage beyond operational capacity.
Slam Joint Detection	Tool slammed into fastener.	Bring reaction bar slowly into position.
Battery Error	Flat Battery / Overheated Battery	Charge Battery / Allow Battery to cool
Battery Error	Battery connection fault	Contact Snap-on®
Battery charger right hand LED flashes yellow	Battery pack is either too hot or too cold	Wait for battery temperature to be between 32°F (0°C) and 113°F (45°C)
Battery charger right hand LED flashes red	Battery pack is faulty	Replace battery
Message “Mode2>>Mode1. No Torque Only Targets”	No torque only targets	Create a torque only target then change to MODE 1 (Torque Only)
Cannot set angle or output communications	In “Torque only” mode	Set Mode to “Advanced”

GLOSSARY OF TERMS

Word or Term	Meaning
A	Amps
Angle Limit	Maximum allowed angle movement in Audit mode
Audit	Checking a pre-tightened joint
Auto reset	Tool will automatically reset ready for the next tightening operation
a.c.	Alternating Current
A/F	Across Flats
Bi-directional	Clockwise and Counter-Clockwise
CSV	Comma Separated Values
CTC123	Snap on® Battery Charger
EvoLog	PC software supplied with CTM tool (not for use with Link tool)
CTB	Snap on® Battery Pack
CTM	Cordless Torque Multiplier
Fastener	Bolt or stud to be tightened
Final Torque	Torque target: Torque value Torque & angle target: The torque when angle complete
Link	Tool for working with ControlTECH controller wireless error proofing system. When in use "CT" will appear on the CTM display. "CT" is shown in red when not connected and green when connected
Nose Extension	A reaction type used where tool access is restricted, a typical example is on wheel nuts on heavy vehicles
PPE	Personal Protective Equipment
Reaction Bar	Item to counteract applied torque. Also called Reaction Plate
Record	A memory location. A Work Group, Work ID, User ID or Result saved in the tools memory
RCD	Residual Current Device, for disconnecting the electrical supply in the case of a fault; so, protecting the operator A device with a trip value of 30mA or less is recommended
Target	The Torque, Torque & Angle or Audit Torque that the tool is set to
Safe to Start	Tool with second trigger button so both hands are located on the tool
Single Trigger	Tool for applications where "safe to start" feature is not practical
Snug	"Snug" refers to the torque applied for a Torque & Angle target
Torque Rate	The increase in torque with angular displacement while advancing a fastener in a threaded joint (as defined in ISO 5393 Rotary Tools for Threaded Fasteners – Performance Test Method.) A LOW torque rate is often referred to as a SOFT joint A HIGH torque rate is often referred to as a HARD joint
Turn Angle	Minimum angle of rotation of a Torque only fastener
User ID	Identification of the person using the tool
V	Volt
Work ID	Identification of a group of Results
Work Group	Specific group of a number of Work IDs and Targets

NOTES

NOTES